

MicroMMAC
LOCAL MANAGEMENT
USER'S GUIDE

CABLETRON
SYSTEMS

The Complete Networking Solution™

NOTICE

Cabletron Systems reserves the right to make changes in specifications and other information contained in this document without prior notice. The reader should in all cases consult Cabletron Systems to determine whether any such changes have been made.

The hardware, firmware, or software described in this manual is subject to change without notice.

IN NO EVENT SHALL CABLETRON SYSTEMS BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING BUT NOT LIMITED TO LOST PROFITS) ARISING OUT OF OR RELATED TO THIS MANUAL OR THE INFORMATION CONTAINED IN IT, EVEN IF CABLETRON SYSTEMS HAS BEEN ADVISED OF, KNOWN, OR SHOULD HAVE KNOWN, THE POSSIBILITY OF SUCH DAMAGES.

© Copyright 1996 by Cabletron Systems, Inc., P.O. Box 5005, Rochester, NH 03866-5005

All Rights Reserved

Printed in the United States of America

Order Number: 9031838-01 June 1996

SPECTRUM, **LANVIEW**, **MicroMMAC**, and **BRIM** are registered trademarks and **Element Manager**, **EPIM**, **EPIM-A**, **EPIM-F1**, **EPIM-F2**, **EPIM-F3**, **EPIM-T**, **EPIM-X**, **FOT-F**, **FOT-F3**, **HubSTACK**, **SEH**, **SEHI**, and **TMS-3** are trademarks of Cabletron Systems, Inc.

All other product names mentioned in this manual may be trademarks or registered trademarks of their respective companies.

Printed on



Recycled Paper

FCC NOTICE

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment uses, generates, and can radiate radio frequency energy and if not installed in accordance with the operator's manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause interference in which case the user will be required to correct the interference at his own expense.

WARNING: Changes or modifications made to this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

DOC NOTICE

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la class A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

VCCI NOTICE

This equipment is in the 1st Class Category (information equipment to be used in commercial and/or industrial areas) and conforms to the standards set by the Voluntary Control Council for Interference by Information Technology Equipment (VCCI) aimed at preventing radio interference in commercial and/or industrial areas.

Consequently, when used in a residential area or in an adjacent area thereto, radio interference may be caused to radios and TV receivers, etc.

Read the instructions for correct handling.

この装置は、第一種情報装置（商工業地域において使用されるべき情報装置）で商工業地域での電波障害防止を目的とした情報処理装置等電波障害自主規制協議会（VCCI）基準に適合しております。

従って、住宅地域またはその隣接した地域で使用すると、ラジオ、テレビジョン受信機等に受信障害を与えることがあります。

取扱説明書に従って正しい取り扱いをして下さい。

CABLETRON SYSTEMS, INC. PROGRAM LICENSE AGREEMENT

IMPORTANT: Before utilizing this product, carefully read this License Agreement.

This document is an agreement between you, the end user, and Cabletron Systems, Inc. ("Cabletron") that sets forth your rights and obligations with respect to the Cabletron software program (the "Program") contained in this package. The Program may be contained in firmware, chips or other media. BY UTILIZING THE ENCLOSED PRODUCT, YOU ARE AGREEING TO BECOME BOUND BY THE TERMS OF THIS AGREEMENT, WHICH INCLUDES THE LICENSE AND THE LIMITATION OF WARRANTY AND DISCLAIMER OF LIABILITY. IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT, PROMPTLY RETURN THE UNUSED PRODUCT TO THE PLACE OF PURCHASE FOR A FULL REFUND.

CABLETRON SOFTWARE PROGRAM LICENSE

1. **LICENSE.** You have the right to use only the one (1) copy of the Program provided in this package subject to the terms and conditions of this License Agreement.

You may not copy, reproduce or transmit any part of the Program except as permitted by the Copyright Act of the United States or as authorized in writing by Cabletron.
2. **OTHER RESTRICTIONS.** You may not reverse engineer, decompile, or disassemble the Program.
3. **APPLICABLE LAW.** This License Agreement shall be interpreted and governed under the laws and in the state and federal courts of New Hampshire. You accept the personal jurisdiction and venue of the New Hampshire courts.

EXCLUSION OF WARRANTY AND DISCLAIMER OF LIABILITY

1. **EXCLUSION OF WARRANTY.** Except as may be specifically provided by Cabletron in writing, Cabletron makes no warranty, expressed or implied, concerning the Program (including its documentation and media).

CABLETRON DISCLAIMS ALL WARRANTIES, OTHER THAN THOSE SUPPLIED TO YOU BY CABLETRON IN WRITING, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WITH RESPECT TO THE PROGRAM, THE ACCOMPANYING WRITTEN MATERIALS, AND ANY ACCOMPANYING HARDWARE.
2. **NO LIABILITY FOR CONSEQUENTIAL DAMAGES.** IN NO EVENT SHALL CABLETRON OR ITS SUPPLIERS BE LIABLE FOR ANY DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS, PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR RELIANCE DAMAGES, OR OTHER LOSS) ARISING OUT OF THE USE OR INABILITY TO USE THIS CABLETRON PRODUCT, EVEN IF CABLETRON HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, OR ON THE DURATION OR LIMITATION OF IMPLIED WARRANTIES, IN SOME INSTANCES THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU.

UNITED STATES GOVERNMENT RESTRICTED RIGHTS

The enclosed product (a) was developed solely at private expense; (b) contains “restricted computer software” submitted with restricted rights in accordance with Section 52227-19 (a) through (d) of the Commercial Computer Software - Restricted Rights Clause and its successors, and (c) in all respects is proprietary data belonging to Cabletron and/or its suppliers.

For Department of Defense units, the product is licensed with “Restricted Rights” as defined in the DoD Supplement to the Federal Acquisition Regulations, Section 52.227-7013 (c) (1) (ii) and its successors, and use, duplication, disclosure by the Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at 252.227-7013. Cabletron Systems, Inc., 35 Industrial Way, Rochester, New Hampshire 03867-0505.

CONTENTS

CHAPTER 1 INTRODUCTION

1.1	Using This Manual	1-1
1.2	Manual Organization	1-1
1.3	Local Management Overview	1-2
1.3.1	The Management Agent	1-2
1.3.2	In-Band vs. Out-of-Band	1-3
1.3.3	Local vs. Remote Management	1-3
1.4	Local Management Requirements.....	1-3
1.5	Local Management Screen Elements.....	1-4
1.6	Local Management Keyboard Conventions.....	1-6
1.7	Navigating Local Management Screens.....	1-7
1.8	Document Conventions	1-8
1.9	Related Documents	1-8
1.10	Getting Help.....	1-8

CHAPTER 2 LOCAL MANAGEMENT REQUIREMENTS

2.1	Configuring a Local Management Terminal.....	2-1
2.2	Management Terminal Setup Requirements.....	2-2
2.2.1	Cable Configuration for the Management Terminal	2-3
2.2.2	Cable Configuration for the UPS	2-4
2.3	Establishing a Telnet Connection	2-4

CHAPTER 3 ACCESSING LOCAL MANAGEMENT

3.1	Using the Menu Screens	3-1
3.2	Navigating Local Management Screens.....	3-2
3.2.1	Selecting Local Management Menu Screen Items	3-3
3.2.2	Exiting Local Management Screens	3-4
3.2.3	Exiting the Local Management Session.....	3-4
3.3	The Main Menu Screen	3-5
3.4	The Setup Menu Screen.....	3-6
3.5	The Status Menu Screen.....	3-7

CHAPTER 4 SYSTEM LEVEL SCREEN

4.1 System Level Screen Fields4-2

4.2 Setting the System Date4-4

4.3 Setting the System Time4-5

4.4 Setting the Host IP Address4-5

4.5 Setting the Out of Band IP Address4-6

4.6 Setting the Default Gateway4-6

4.7 Setting the Subnet Mask4-7

4.8 Setting the Default Interface4-7

4.9 COM Port Applications.....4-8

 4.9.1 Configuring the COM Ports4-8

 4.9.2 Configuring the COM Port Baud Rate4-9

CHAPTER 5 SNMP COMMUNITY NAMES SCREEN

5.1 Community Name Access Policy5-2

5.2 Setting SNMP Community Names5-2

CHAPTER 6 SNMP TRAPS SCREEN

6.1 Trap Table Screen Fields.....6-2

6.2 Setting the SNMP Trap Destination6-2

CHAPTER 7 FLASH DOWNLOAD SCREEN

7.1 Selecting a Flash Download Method7-2

 7.1.1 Runtime Download7-2

 7.1.2 Bootprom Download.....7-3

CHAPTER 8 BRIDGE SETUP SCREEN

8.1 Bridge Setup Screen Fields8-2

8.2 Selecting a Spanning Tree Protocol8-2

8.3 Selecting the Port Administrative Status8-3

8.4 Selecting the Bridge Port Pair Administrative Status8-4

CHAPTER 9 COMPONENT STATUS SCREEN

CHAPTER 10 BRIDGE STATISTICS SCREEN

10.1 Bridge Statistics Screen Fields10-1

10.2 Selecting an Update-Freq10-4

10.3 Selecting an Interface/Module/Port.....10-4

10.4 Enabling Ports.....10-5

10.5 Disabling Ports10-5

CHAPTER 11 MIB NAVIGATOR SCREEN

11.1	Managing Device MIBs.....	11-2
11.2	MIB Navigator Command Set Overview.....	11-3
11.2.1	Conventions for MIB Navigator Commands	11-4
11.2.2	Navigation Commands	11-5
11.2.3	Other Commands	11-11
11.2.4	Special Commands.....	11-17

CHAPTER 1

INTRODUCTION

Welcome to the Cabletron Systems **MicroMMAC Local Management User's Guide**. This manual explains how to access and use Cabletron Systems Local Management for the MicroMMAC. Local Management provides monitoring and control services for the MicroMMAC and its attached segments.

1.1 USING THIS MANUAL

A general working knowledge of basic network operations and an understanding of management applications is helpful prior to using Cabletron Systems Local Management.

This manual describes how to:

- Access the Local Management application
- Identify and operate the types of fields used by Local Management
- Navigate through Local Management fields and menus
- Use Local Management screens to perform management operations

1.2 MANUAL ORGANIZATION

The following summarizes the organization of this manual.

Chapter 1, **Introduction**, outlines the contents of this manual, provides an overview of Local Management, and explains how to use the management screens.

Chapter 2, **Local Management Requirements**, describes the setup requirements for accessing Local Management. It also explains how to configure a management terminal and connect it to the MicroMMAC.

Chapter 3, **Accessing Local Management**, describes how to access the Main Menu screen and navigate the Local Management screens.

Chapter 4, **System Level Screen**, describes how to use the System Level screen, its functions, and operations.

Chapter 5, **SNMP Community Names Screen**, explains how to control access to the MicroMMAC by assigning community names.

Chapter 6, **SNMP Traps Screen**, explains how to configure the MicroMMAC to send SNMP traps to multiple network management stations.

Chapter 7, **Flash Download Screen**, describes how to download a new firmware image to the MicroMMAC.

Chapter 8, **Bridge Setup Screen**, describes how to configure the MicroMMAC for bridge functions.

Chapter 9, **Component Status Screen**, discusses how to view the status of MicroMMAC MIB components.

Chapter 10, **Bridge Statistics Screen**, discusses how to configure the MicroMMAC to gather statistics for each interface, module, and port.

Chapter 11, **MIB Navigator Screen**, describes how to access and use the MIB Navigator screen. This chapter also includes examples for MIB Navigator commands.

1.3 LOCAL MANAGEMENT OVERVIEW

Cabletron Systems Local Management is a management tool that allows a network manager to perform the following tasks:

- Configure interconnected devices to form a network
- Monitor the performance of the network
- Control user access to the network and its components for the purpose of security

1.3.1 The Management Agent

The management agent is a processor within the MicroMMAC which collects statistical information (e.g., frames received, errors detected) about the managed network's operational performance. Local Management communicates with the management agent for the purpose of viewing statistics or issuing management commands to network devices.

1.3.2 In-Band vs. Out-of-Band

Network management systems are often classified as either in-band or out-of-band. In-band network management passes data along the same medium (cables, frequencies) used by all other stations on the network. An example of an in-band network management system is Cabletron Systems SPECTRUM.

Out-of-band network management passes data along a medium that is entirely separate from the network's common data carrier, for example, a cable connection between a dumb terminal and the COM port of the MicroMMAC. Cabletron Systems Local Management is an out-of-band network management system.

A device connected out-of-band to the management agent is not connected to the LAN. This type of connection allows you to communicate with a network device even when that device is unable to communicate through the network, for example, at the time of installation.

1.3.3 Local vs. Remote Management

Network management applications are usually described as either local or remote management applications. Local management applications reside within the circuits of the management device's management agent. Remote management applications run within the circuits of another device that provides management services. This allows you to perform network management from a remote location.

1.4 LOCAL MANAGEMENT REQUIREMENTS

The MicroMMAC provides two communication ports. Each port supports a management terminal connection. To access Local Management, connect one of the following systems to either COM 1 or COM 2:

- Digital Equipment Corporation VT series terminal
- VT type terminal running emulation programs for the Digital Equipment Corporation VT series
- IBM or compatible PC running a VT series emulation software package

You can also access Local Management using a Telnet connection through one of the network ports of the MicroMMAC.

1.5 LOCAL MANAGEMENT SCREEN ELEMENTS

Local Management screens consist of five basic elements, or fields. Figure 1-1 shows a Local Management screen and points out the various types of fields.




Figure 1-1 Sample Local Management Screen

The following list explains each of the Local Management fields:

Event Message Field

This field briefly displays messages that indicate if a Local Management procedure was executed correctly or incorrectly, that changes were saved or not saved to Non-Volatile Random Access Memory (NVRAM), or that a user did not have access privileges to an application.

Table 1-1 describes the most common event messages. Event messages related to specific Local Management applications are described with those applications throughout this manual.

Table 1-1 Event Messages

Message	Meaning
SAVED OK	One or more fields were modified, and saved to NVRAM.
NOT SAVED?--PRESS SAVE TO KEEP CHANGES	One or more fields were modified, but not yet saved to NVRAM.
NOTHING TO SAVE	The SAVE command was executed, but nothing was saved to NVRAM.

Display Fields

Display fields can not be edited. These fields may display information which never changes, or information which may change as a result of Local Management operations, user selections, or network monitoring information.

Input Fields

Input fields require the entry of keyboard characters. IP addresses, System Date, and System Time are examples of Input fields.

Selection Fields

Selection fields provide a series of possible values. Only applicable values appear in selection fields.

Command Fields

Command fields are located at the bottom of Local Management screens. Command fields are used to exit Local Management screens and to save Local Management entries.

1.6 LOCAL MANAGEMENT KEYBOARD CONVENTIONS

All key names appear in this manual as capital letters. For example, the Enter key appears as ENTER, the Escape key appears as ESC, and the Backspace key appears as BACKSPACE. Table 1-2 explains the keyboard conventions used in this manual as well as the key functions.

Table 1-2 Keyboard Conventions

Key	Function
ENTER and RETURN	These are selection keys that perform the same Local Management function. For example, "Press ENTER" means that you can press either ENTER or RETURN, unless this manual specifically instructs you otherwise.
ESC	This key lets you escape from a Local Management screen without saving your changes. For example, "Press ESC twice" means that you must quickly press the ESCAPE key two times to exit the Local Management screen.
SPACE and BACKSPACE	These keys cycle through selections in some Local Management fields. Press SPACE to cycle forward through selections and Press BACKSPACE to cycle backward through selections.
Arrows	These are navigation keys. Use the UP-ARROW, DOWN-ARROW, LEFT-ARROW, and RIGHT-ARROW keys to move the screen cursor. For example, "Use the arrow keys" means to press whichever arrow key moves the cursor to the desired field on the Local Management screen.
SHIFT-[+/=]	This key combination increments values in some Local Management selection fields. For example, "Press SHIFT-[+/=]" means to hold down the SHIFT key while pressing the PLUS/EQUAL key.

Table 1-2 Keyboard Conventions (Continued)

[-]	This key decreases values from some Local Management selection fields. For example, "Press [-]" means to press the MINUS key.
DEL	The DEL (Delete) key removes characters from a Local Management Selection field. For example, "Press DEL" means to press the DELETE key.

1.7 NAVIGATING LOCAL MANAGEMENT SCREENS


To navigate within a Local Management screen, use the arrow keys of the terminal or the workstation providing terminal emulation services. The Local Management screen cursor responds to the LEFT-ARROW, RIGHT-ARROW, UP-ARROW, and DOWN-ARROW keys. Each time you press an arrow key, the Local Management screen cursor moves to the next available field in the direction of the arrow key.

The Local Management screen cursor only moves to fields which can be selected or used for input. This means that the cursor jumps over display fields and empty lines on the Local Management screen.

The Local Management screen cursor provides wrap-around operation. This means that a cursor located at the edge of a screen, when moved in the direction of that edge, "wraps around" to the outermost selectable item on the opposite side of the screen which is on the same line or column.

1.8 DOCUMENT CONVENTIONS

The following conventions are used throughout this document:



Note symbol. Calls the reader's attention to any item of information that may be of special importance.



Tip symbol. Conveys helpful hints concerning procedures or actions.



Caution symbol. Contains information essential to avoid damage to the equipment or poor network performance.

1.9 RELATED DOCUMENTS

Use the following manuals to supplement the procedures and other technical data provided in this manual. The procedures contained in the following manuals are referenced where appropriate, but not repeated in this manual.

- Cabletron Systems *MicroMMAC 10BASE-T Intelligent Stackable Hub Installation Guide*
- Cabletron Systems BRIM User's Guides

1.10 GETTING HELP

If you need additional support related to Local Management, or if you have any questions, comments, or suggestions concerning this manual, contact Cabletron Systems Technical Support:

By phone	(603) 332-9400 Monday – Friday; 8 A.M. – 8 P.M. Eastern Time
By CompuServe	GO CTRON from any ! prompt
By Internet mail	support@ctron.com
By FTP	ctron.com (134.141.197.25)
Login	<i>anonymous</i>
Password	<i>your email address</i>

Before calling Cabletron Systems Technical Support, have the following information ready:

- A description of the failure
- A description of any action(s) already taken to resolve the problem (e.g., changing mode switches, rebooting the unit, etc.)
- A description of your network environment (layout, cable type, etc.)
- Network load and frame size at the time of trouble (if known)
- The serial and revision numbers of all Cabletron Systems products in the network
- The device history (i.e., have you returned the device before, is this a recurring problem, etc.)
- Any previous Return Material Authorization (RMA) numbers

CHAPTER 2

LOCAL MANAGEMENT REQUIREMENTS

This chapter describes how to attach a Local Management terminal to the Cabletron Systems host device, and lists the setup and configuration requirements for the following equipment:

- Console/terminal
- Console cable
- Console cable connections

2.1 CONFIGURING A LOCAL MANAGEMENT TERMINAL

The following instructions explain how to configure your management terminal (console) to communicate with Local Management. Refer to your specific management terminal manual for more instructions if necessary.

To access Local Management, use one of the following systems:

- Digital Equipment Corporation VT series terminal
- VT type terminal running emulation programs for the Digital Equipment Corporation VT series
- IBM or compatible PC running a VT series emulation software package

2.2 MANAGEMENT TERMINAL SETUP REQUIREMENTS

Table 2-1 lists the setup parameters for the management terminal. If the management terminal is a Digital Equipment Corporation VT320 terminal, press F3 to access the Setup Directory. If the management terminal uses terminal emulation of the VT320, refer to the equipment user manual for setup procedures.

Table 2-1 Terminal Setup Parameters

Menu	Function	Selection
Display Setup	Columns	80 Columns
	Controls	Interpret Controls
	Auto Wrap	No Auto Wrap
	Test Cursor	Cursor
General Setup	Mode	7 Bit Control
	Cursor Keys	Normal Cursor Keys
Communications Setup	Transmit	Transmit = 9600
	Receive	Receive = Transmit
	XOFF	any option
	Bits, Parity	8 Bits, No Parity
	Stop Bit	1 Stop Bit
	Local Echo	No Local Echo
	Port	DEC-423, Data Leads Only
	Transmit	any option
	Auto Answerback	No Auto Answerback
Keyboard Setup	Auto Repeat	any option
	Keyclick	any option
	Margin Bell	Margin Bell
	Warning Bell	Warning Bell
	Auto Answerback	No Auto Answerback

2.2.1 Cable Configuration for the Management Terminal

This section outlines the proper cable configurations to connect a management terminal to the MicroMMAC.

You need an adapter kit containing the following items to connect a terminal to the MicroMMAC:

- One RS232 cable
- One VT series adapter
- One VT series device cable

The adapter you use depends on whether you connect a VT320 terminal or a PC emulating a VT320 to the MicroMMAC COM port. Read the information included with the adapter kit to make sure that you are using the correct adapter.

To configure the cables, perform the following steps:

1. Plug a straight-through twisted pair cable (e.g., an RS232 cable) into the MicroMMAC's COM 1 or COM 2 port.
2. Plug the other end of the RS232 cable into the adapter.
3. Connect the adapter into the VT series device cable and plug the other end of the VT series device cable into the terminal.
4. Power on the terminal. The message "VT320 OK" appears on the screen indicating that the cables are properly configured to the VT terminal.

2.2.2 Cable Configuration for the UPS

To configure a cable from the Uninterruptible Power Supply (UPS) to a host device perform the following steps:

1. Plug a straight-through twisted pair, RS232, cable into the COM 1 or COM 2 port.
2. Plug the other end of the RS232 cable into the adapter (Part No. 9372066) and connect the adapter to the UPS.

After the cable configuration is complete, use one of the following management tools to configure the COM port for UPS application:

- Local Management – Chapter 4, **System Level Screen** of this manual provides instructions for setting up the COM 1 and COM 2 ports for the UPS application.
- Graphical user interfaces provided by SPECTRUM Element Manager for Windows, SPECTRUM Portable Management Applications (SPMAs), or SPECTRUM software packages.

2.3 ESTABLISHING A TELNET CONNECTION

Once the MicroMMAC has a valid IP address, you can establish a Telnet session with Local Management from any TCP/IP based node on the network. Telnet connections to the host device require the community name passwords assigned at the SNMP Community Names screen. Refer to the SNMP Community Names section of this manual for additional information about community names.



See the instructions included with the Telnet application for information about establishing a Telnet session.

CHAPTER 3

ACCESSING LOCAL MANAGEMENT

This chapter explains how to access and use the Local Management menu screens. Menu screens provide a path to the setup screens, statistic screens, and status screens.

3.1 USING THE MENU SCREENS

Verify that your terminal has been properly connected to the MicroMMAC before proceeding.

To access Local Management, perform the following steps:

1. Power on the terminal. The message “VT320 OK” appears on the terminal screen.
2. Press RETURN two times. The first RETURN activates Auto-Baud Detection and the second RETURN displays the MicroMMAC Password screen, Figure 3-1.

MicroMMAC Local Management

CABLETRON Systems, Incorporated
P.O. Box 5005
Rochester, NH 03867-5005 USA
(603) 332-9400

(c) Copyright CABLETRON Systems, Inc. 19XX


Flash Image Version: XX.XX.XX
BOOTPROM Version: XX.XX.XX

Board Revision: X.X
Enter Password: XXXXXXXXXX

090820

Figure 3-1 The MicroMMAC Password Screen

3. Enter your password and press ENTER. The default super-user access password is “*public*” or press ENTER.



Your password is one of the community names specified in the SNMP Community Names screen. Access to certain Local Management capabilities depends on the degree of access accorded that community name. See the SNMP Community Names section.


- If you enter an invalid password the cursor returns to the beginning of the password entry field.
- If you enter a valid password, the associated access level displays at the bottom of the screen and the Main Menu screen, Figure 3-3, appears.
- If no activity occurs for several minutes the Password screen reappears indicating that you must re-enter the password.

3.2 NAVIGATING LOCAL MANAGEMENT SCREENS

Local Management consists of a series of menu screens that provide a path to each of the Local Management function screens. You navigate through Local Management by selecting items from the menu screens. MicroMMAC Local Management consists of the following menu screens:

- Main Menu screen
- Setup Menu screen
- Status Menu screen
- Statistics Menu screen

Figure 3-2 shows the hierarchy of Local Management screens.



090830

Figure 3-2 Hierarchy of Local Management Screens

3.2.1 Selecting Local Management Menu Screen Items

To select items on a Local Management menu screen, perform the following steps:

1. Use the arrow keys to highlight a menu item.
2. Press ENTER. The selected Local Management menu screen appears.

3.2.2 Exiting Local Management Screens

To exit any of the Local Management screens, perform the following steps:

1. Use the arrow keys to highlight the **RETURN** command at the bottom of the Local Management screen.
2. Press ENTER. The previous screen in the Local Management hierarchy appears.



You can also exit Local Management screens by pressing ESC twice. This exit method does not warn you about unsaved changes and all unsaved changes will be lost.


3.2.3 Exiting the Local Management Session

To exit from MicroMMAC Local Management, perform the following steps:

1. Use the arrow keys to highlight the **RETURN** command at the bottom of the Local Management screen.
2. Press ENTER. The previous screen in the Local Management hierarchy appears.
3. Repeat steps 1 and 2 until the Main Menu screen appears.
4. Use the arrow keys to highlight the **EXIT** command at the bottom of the Main Menu screen.
5. Press ENTER. The MicroMMAC Local Management Password screen appears and the Local Management session ends.

3.3 THE MAIN MENU SCREEN

The Main Menu screen is the starting point from which all the Local Management screens are accessed. Figure 3-3 shows the Main Menu screen.



090821


Figure 3-3 The Main Menu

The Main Menu screen displays the following menu items:

- **Setup Menu** – The Setup Menu provides access to Local Management screens that are used to configure the MicroMMAC.
- **Status Menu** – The Status Menu provides access to the Component Status screen which displays the operational and administrative status of MicroMMAC MIB components.
- **Statistics Menu** – The Statistics Menu provides bridge statistics and performance information for devices managed by the MicroMMAC in the network.
- **MIB Navigator** – The MIB Navigator is a Local Management utility which allows the user to access, monitor, and set specific Management Information Base (MIB) items within the MicroMMAC.

3.4 THE SETUP MENU SCREEN

The Setup Menu screen provides access to Local Management screens that are used to configure or alter the configuration of the MicroMMAC. Examples of functions accessible through the Setup Menu include configuring the host IP address and subnet mask, assigning SNMP community names, and configuring SNMP trap notification. Figure 3-4 shows the Setup Menu.



090822


Figure 3-4 The Setup Menu

The Setup Menu displays the following menu items (the Flash Download screen and the Bridge Setup screen are discussed later in this manual):


- **System Level** – The System Level Setup screen allows you to configure basic operating parameters for the MicroMMAC.
- **SNMP Community Names** – The SNMP Community Names Setup screen allows you to change or review the community names used as access passwords for local management operation.
- **SNMP Traps** – The SNMP Traps Setup screen provides display and configuration access to the table of IP addresses used for trap destinations and associated community names.

3.5 THE STATUS MENU SCREEN

Figure 3-5 shows the Status Menu screen. The Status Menu screen provides access to the Chassis Status screen and Component Status screen.



The MicroMMAC does not use the Chassis Status screen.



090826

Figure 3-5 The Status Menu Screen

CHAPTER 4

SYSTEM LEVEL SCREEN

This chapter explains how to use the System Level screen to set the following parameters:

- System Date
- System Time
- Host IP Address
- Out of Band IP Address
- Subnet Mask
- Default Gateway
- Default Interface
- COM 1 and COM 2 Port Applications

4.1 SYSTEM LEVEL SCREEN FIELDS

Figure 4-1 shows the MicroMMAC System Level screen.

Event Message Line

MicroMMAC Local Management

Flash Image Version XX.XX.XX

SYSTEM LEVEL

System Date: 12/30/95

System Time: 14:23:00

Host IP Address 000.000.000.000

Subnet Mask 255.255.0.0

Phys Address 00-00-1D-16-26-F8

Out of Band IP Addr 0.0.0.0

Default Gateway NONE DEFINED

Default Interface NONE DEFINED

COM 1 Application: [LM]

COM 2 Application: [SLIP]

COM2 Baud Rate: NO_FRAMEWORK_ERROR

SAVE

RETURN

Field Sensitive Help Line

090823

Figure 4-1 The System Level Screen

The following definitions explain each System Level screen field. The sections which follow these definitions explain the use of these fields.

System Date

Use this field to enter the system date.

System Time

Use this field to enter the system time.

Host IP Address

Use this field to enter the IP address of the MicroMMAC.

Out of Band IP Addr

Use this field to enter the out of band IP address for a MicroMMAC communications port (COM 1 or COM 2) configured for a Serial Line Internet Protocol (SLIP) session.

Subnet Mask

Use this field to enter the subnet mask for the MicroMMAC. Subnets are logical divisions of the network that isolate groups of devices. The subnet mask determines how the MicroMMAC directs SNMP traps to a management workstation. If the MicroMMAC resides on the same network as the management workstation, then the MicroMMAC sends SNMP traps directly to the management workstation. If the MicroMMAC resides on a different subnet as the management workstation, then the MicroMMAC sends SNMP traps to a gateway or router.

- Use the subnet mask default setting, 255.255.0.0, when the management workstations designated to receive SNMP traps reside on the same network as the MicroMMAC.
- Set a new value for the subnet mask when management workstations designated to receive SNMP traps reside on a different subnet (for example, across a gateway or router).

Default Gateway

Use this field to enter the default gateway for the MicroMMAC. The default gateway is the IP address of the network device (gateway or router) used to forward SNMP traps to a management station. The default setting for this field is NONE DEFINED.

Phys Address

This field displays the physical address of the MicroMMAC. You cannot modify the physical address.

Default Interface

Use this field to select the default interface for the MicroMMAC's default gateway. The default interface is the channel that is set up to handle SNMP traps sent to an IP station that is not on the same subnet as the MicroMMAC in an IP routed environment. The default setting for this field is NONE DEFINED.

COM 1 Application

Use this field to select the communication port's application. Settings for this field are UNASSIGNED, SLIP, UPS, or LM.

COM 2 Application

Use this field to select the communication port's application. Settings for this field are UNASSIGNED, SLIP, UPS, or LM.

Baud Rate


This field only appears when the COM 1 or the COM 2 Application field is set to SLIP. The default setting for this field is

NO_FRAMEWORK_ERROR. The MicroMMAC uses Auto-Baud Detection which automatically detects the Baud rate for the MicroMMAC.

4.2 SETTING THE SYSTEM DATE

To set the system date, perform the following steps:

1. Use the arrow keys to highlight the **System Date** field.
2. Enter the date in a MM/DD/YY format.



When entering the date in the system date field, you do not need to add separators between month, day, and year numbers, as long as each entry uses two decimal numbers. For example, to set the date to 03/17/96, type "031796" in the System Date field.


3. Press ENTER to set the system calendar.
4. Use the arrow keys to highlight the **SAVE** command at the bottom of the screen and press ENTER.

If the date entered was a valid format, the Event Message field at the top of the screen displays "SAVED OK." If the entry was not valid, Local Management does not alter the current value and refreshes the System Date field with the previous value.

4.3 SETTING THE SYSTEM TIME

To set the system clock, perform the following steps:

1. Use the arrow keys to highlight the **System Time** field.
2. Enter the time in a 24-hour format, HH:MM:SS.



When entering the time in the system time field, you do not need to add separators between hours, minutes, and seconds, as long as each entry uses two decimal numbers. For example, to set the time to 6:45 a.m., type “064500” in the System Time field.

3. Press ENTER to set the system clock.
4. Use the arrow keys to highlight the **SAVE** command field at the bottom of the screen and press ENTER.

If the time entered was a valid format, the Event Message field at the top of the screen displays “SAVED OK.” If the entry was not valid, Local Management does not alter the current value and refreshes the System Time field with the previous value.

4.4 SETTING THE HOST IP ADDRESS

To set the host IP address, perform the following steps:

1. Use the arrow keys to highlight the **Host IP Address** field.
2. Enter the IP address using Decimal Dotted Notation (DDN) format.

For example: 134.141.25.17

3. Press ENTER. If the IP address entered was a valid format, the cursor returns to the beginning of the Host IP Address field. If the entry was not valid, the Event Message field displays “INVALID IP ADDRESS OR FORMAT ENTERED.” Local Management does not alter the current value and refreshes the Host IP Address field with the previous value.
4. Use the arrow keys to highlight the **SAVE** command field.
5. Press ENTER. The Event Message field at the top of the screen displays “SAVED OK.”

4.5 SETTING THE OUT OF BAND IP ADDRESS

To set the Out of Band IP Address, perform the following steps:

1. Use the arrow keys to highlight the **Out of Band IP Addr** field.
2. Enter the IP address using Decimal Dotted Notation (DDN) format.

For example: 134.141.25.17

3. Press ENTER. If the IP address entered was a valid format, the cursor returns to the beginning of the Out of Band IP Address field. If the entry was not valid, the Event Message field displays “INVALID IP ADDRESS OR FORMAT ENTERED.” Local Management does not alter the current value and refreshes the IP Address field with the previous value.
4. Use the arrow keys to highlight the **SAVE** command field.
5. Press ENTER. The Event Message field at the top of the screen displays “SAVED OK.”

4.6 SETTING THE DEFAULT GATEWAY

To set the default gateway, perform the following steps:

1. Use the arrow keys to highlight the **Default Gateway** field.
2. Enter the IP address of the default gateway using DDN format.

For example: 134.141.79.121

3. Press ENTER. If the default gateway address entered was a valid format, the cursor returns to the beginning of the Default Gateway field. If the entry was not valid, the Event Message field displays “INVALID DEFAULT GATEWAY OR FORMAT ENTERED.” Local Management does not alter the current value and refreshes the Default Gateway field with the previous value.
4. Use the arrow keys to highlight the **SAVE** command field.
5. Press ENTER. The Event Message field at the top of the screen displays “SAVED OK.”

4.7 SETTING THE SUBNET MASK

Subnets are logical divisions of the network. To change the subnet mask from its default value, perform the following steps:

1. Use the arrow keys to highlight the **Subnet Mask** field.
2. Enter the subnet mask using Decimal Dotted Notation (DDN) format. Values for each decimal must range from 0-255.

For example: 255.255.0.0

3. Press ENTER. If the subnet mask entered was a valid format, the cursor returns to the beginning of the Subnet Mask field. If the entry was not valid, the Event Message field displays “INVALID SUBNET MASK OR FORMAT ENTERED.” Local Management does not alter the current value and refreshes the Subnet Mask field with the previous value.
4. Use the arrow keys to highlight the **SAVE** command field.
5. Press ENTER. The Event Message field at the top of the screen displays “SAVED OK.”

4.8 SETTING THE DEFAULT INTERFACE

To set the default interface, perform the following steps:

1. Use the arrow keys to highlight the **Default Interface** field.
2. Enter the interface number for the default gateway in this field.
3. Press ENTER. If the interface entered was a valid format, the cursor returns to the beginning of the Subnet Mask field. If the entry was not valid, the Event Message field displays “PERMISSIBLE RANGE: 1...1.” Local Management does not alter the current value and refreshes the Default Interface field with the previous value.
4. Use the arrow keys to highlight the **SAVE** command field.
5. Press ENTER. The Event Message field at the top of the screen displays “SAVED OK.”

4.9 COM PORT APPLICATIONS

The MicroMMAC communication ports, COM 1 and COM 2, support the following applications:



Refer to the Release Notes included with the MicroMMAC to verify which communication port applications are currently supported.

- Cabletron Systems Local Management connections
- American Power Conversion (APC) Uninterruptible Power Supply (UPS) management connections
- Telnet connections to a wide area network via the Serial Line Internet Protocol (SLIP)

4.9.1 Configuring the COM Ports

To configure the COM 1 and COM 2 ports, perform the following steps:

1. Use the arrow keys to highlight the **COM 1 Application** or the **COM 2 Application** field.



Use caution not to alter the settings of the port which is operating the current Local Management connection. This could disconnect the Local Management terminal from the port and end the Local Management session.

2. Press SPACE or BACKSPACE to cycle through the available settings until the operation you require appears. Table 4-1 lists the available settings and their corresponding applications.

Table 4-1 COM Port Application Settings

Setting	Application
LM	Local Management Session
UPS	APC Power Supply SNMP Proxy
SLIP	Serial Line Internet Protocol
UNASSIGNED	Not Active

3. Press ENTER.
4. Use the arrow keys to highlight the **SAVE** command field.
5. Press ENTER. The Event Message field at the top of the screen displays “SAVED OK.”

4.9.2 Configuring the COM Port Baud Rate

If you select SLIP as the COM port application, an additional field appears to the right of the port field. This is the Baud Rate field. The Baud Rate field allows the port operating SLIP to be set to the correct baud rate for its modem connection.

To alter and set the SLIP baud rate, perform the following steps:

1. Use the arrow keys to highlight the **COM X Baud Rate** field.
2. Press SPACE or BACKSPACE to cycle through the available baud rates for SLIP operation.



The COM 1 and COM 2 ports support standard baud rates between 300 and 19,200.

3. Press ENTER to select the desired baud rate.
4. Use the arrow keys to highlight the **SAVE** command field.
5. Press ENTER. The Event Message field at the top of the screen displays “SAVED OK.”

CHAPTER 5

SNMP COMMUNITY NAMES SCREEN

This chapter explains how to assign community names. Community names allow you to control Local Management access by establishing three passwords. Each password controls varying levels of access to MicroMMAC Local Management. Figure 5-1 shows the SNMP Community Names screen.

Event Message Line

MicroMMAC Local Management

Flash Image Version: XX.XX.XX

SNMP COMMUNITY NAMES

Community Name	Access Policy
public	read-only
public	read-write
public	super-user

SAVE

RETURN

090824

Figure 5-1 The SNMP Community Names Screen

5.1 COMMUNITY NAME ACCESS POLICY

In order to perform any operations on the SNMP Community Names screen, you must have used the super-user community name at the User Password prompt when initiating the Local Management session. The default community name for each access level is *public* or press ENTER.

The following definitions explain each of the three levels of access:

read-only

This access level allows reading of device parameters not including community names.

read-write

This access level allows editing of some device configuration parameters not including changing community names.

super-user

This access level allows full management privileges.

5.2 SETTING SNMP COMMUNITY NAMES

To set a community name, perform the following steps:

1. Use the arrow keys to highlight the community name you want to change.
2. Type the new community name and press ENTER. The old community name text disappears and is replaced by the new community name.
3. Use the arrow keys to highlight the **SAVE** command field.
4. Press ENTER. The Event Message field at the top of the screen displays “SAVED OK.”



If you edit the super-user community name, be certain you do not forget it. If you do, you will be unable to perform Local Management functions without returning the device to its factory default configurations. This will effectively erase any configuration work you may have done.

CHAPTER 6

SNMP TRAPS SCREEN

This chapter explains how to configure the SNMP Traps screen to allow the MicroMMAC to send traps to as many as eight remote management workstations. SNMP traps are messages about network events and device operational statistics. The following sections explain SNMP Trap screen fields and instructions for configuring them. Figure 6-1 shows the SNMP Traps screen.

Event Message Line

MicroMMAC Local Management

Flash Image Version: XX.XX.XX

SNMP TRAPS

Trap Destination	Trap Community Name	Enable Traps
0.0.0.0	<CR>	(NO)
0.0.0.0	<CR>	(NO)
0.0.0.0	<CR>	(NO)
0.0.0.0	<CR>	(NO)
0.0.0.0	<CR>	(NO)
0.0.0.0	<CR>	(NO)
0.0.0.0	<CR>	(NO)
0.0.0.0	<CR>	(NO)

SAVE

RETURN

090825

Figure 6-1 The SNMP Traps Screen

6.1 TRAP TABLE SCREEN FIELDS

The following definitions explain each of the SNMP Traps screen fields:

Trap Destination

Use this field to enter the IP address of the management workstation designated to receive SNMP traps from the MicroMMAC.

Trap Community Name

Use this field to enter the community name of the management workstation with the associated IP address.

Enable Traps

Use this field to enable the transmission of SNMP traps to the management workstation.

6.2 SETTING THE SNMP TRAP DESTINATION

Each management workstation designated to receive SNMP traps from the MicroMMAC must have a valid IP address and community name. To set and enable SNMP trap destination, perform the following steps:

1. Use the arrow keys to highlight the **Trap Destination** field you want to modify.
2. Type the IP address of the management workstation designated to receive SNMP traps from the MicroMMAC. This address must be entered in DDN format.

For example: 134.141.25.17

3. Press ENTER.
4. Use the arrow keys to highlight the **Trap Community Name** field (on the same row as the Trap Destination field).
5. Type the community name of the management workstation.
6. Press ENTER.
7. Use the arrow keys to highlight the **Enable Traps** field (on the same row as the Trap Destination and Trap Community Name you have just configured). The default setting for this field is **NO**.

8. Press SPACE or BACKSPACE to set the field to **YES**.
9. Use the arrow keys to highlight the **SAVE** command field.
10. Press ENTER. The Event Message field at the top of the screen displays “SAVED OK.”

CHAPTER 7

FLASH DOWNLOAD SCREEN

This chapter explains how to use the Flash Download screen to download a firmware image from a tftp server to the MicroMMAC. Figure 7-1 shows the Flash Download screen.



Flash download operations require a properly named download file and a properly configured download server.

Event Message Line

MicroMMAC Local Management

Flash Image Version: XX.XX.XX

FLASH DOWNLOAD

Download Method:

[RUNTIME]

Reboot After Download:

[YES]

Last Image Server IP:

0.0.0.0

Last Image File Name:

c:\tftpboot\i2_proxy.hex

Download Server IP:

0.0.0.0

Download File Name:

c:\tftpboot\i2_proxy.hex

EXECUTE

RETURN

090834

Figure 7-1 The Flash Download Screen

7.1 SELECTING A FLASH DOWNLOAD METHOD

1. Use the arrow keys to highlight the **Download Method** field.
2. Press SPACE or BACKSPACE to select a flash download method.
 - If you select **RUNTIME**, the **Reboot After Download** field appears.
 - If you select **BOOTPROM**, the **Commit to Flash** field and the **TFTP Gateway Server IP** field appear.

7.1.1 Runtime Download

If you select runtime download, perform the following steps:

1. Use the arrow keys to highlight the **Reboot After Download** field.
2. Press SPACE or BACKSPACE to select one of the following:
 - **YES**, if you want the MicroMMAC to reboot and use the new firmware image immediately.
 - **NO**, if you want the MicroMMAC to continue using the existing firmware image without interrupting network operation. The MicroMMAC stores the new firmware image in flash memory. When you reset the MicroMMAC, it boots from flash memory using the new image.
3. Use the arrow keys to highlight the **Download Server IP** field.
4. Type the IP address of the download server and press ENTER.
5. Use the arrow keys to highlight the **Download File Name** field.
6. Type the complete path and filename of the new image file to be downloaded. You must include all directories and subdirectories involved in accessing the file. Type the new entry over the previous entry. For example: c:\images\,micrommac\11011.hex.
7. Press ENTER.
8. Use the arrow keys to highlight the **EXECUTE** command located at the bottom of the Flash Download screen.
9. Press ENTER to begin the download. The MicroMMAC attempts to download the file using the IP address, filename, and path provided. This file is assigned to the Flash memory of the MicroMMAC.

7.1.2 Bootprom Download

If you select a Bootprom download, perform the following steps:

1. Use the arrow keys to highlight the **Commit to Flash** field.
2. Press SPACE or BACKSPACE to select one of the following:
 - **YES**, if you want the MicroMMAC to continue using the existing firmware image without interrupting network operation. The MicroMMAC stores the new firmware image in flash memory. When you reset the MicroMMAC, it boots from flash memory using the new image.
 - **NO**, if you want the MicroMMAC to reboot and use the new firmware image immediately.
3. Use the arrow keys to highlight the **Download Server IP** field.
4. Type the IP address of the download server and press ENTER.
5. Use the arrow keys to highlight the **Download File Name** field.
6. Type the complete path and filename of the new image file to be downloaded. You must include all directories and subdirectories involved in accessing the file. Type the new entry over the previous entry. For example: c:\images\,micrommac\11011.hex.
7. Press ENTER.
8. Use the arrow keys to highlight the **TFTP Gateway Server IP** field.
9. Enter the IP address of the tftp gateway server.
10. Use the arrow keys to highlight the **EXECUTE** command located at the bottom of the Flash Download screen.
11. Press ENTER to begin the download. The MicroMMAC attempts to download the file using the IP address, filename, and path provided. This file is assigned to the Flash memory of the MicroMMAC.

CHAPTER 8

BRIDGE SETUP SCREEN

This chapter explains how to use the Bridge Setup screen to select a Spanning Tree protocol and enable/disable bridge ports. If the MicroMMAC contains a Token Ring BRIM, the lower portion of the Bridge Setup screen contains additional fields which relate to the operation of Token Ring devices. Figure 8-1 shows the Bridge Setup screen.



Token Ring bridge information does not appear in this manual but will be included with the next revision.

Event Message Line

MicroMMAC Local Management

Flash Image Version: XX.XX.XX

BRIDGE SETUP

SPANNING TREE PROTOCOL: [IEEE 802.1]

BRIDGE PORT ADMIN STATUS: PORT XX --> ALL PORTS [ENABLED]

BRIDGE PORT PAIR ADMIN STATUS: PORT XX --> PORT [YY] [ENABLED]

This section appears only if device is Token Ring or if Token Ring BRIM is installed.

BRIDGE PORT TYPE [SRT]

RING NUMBER (1-FFF): 001

HOP COUNT LIMIT (1-E): 7

SINGLE ROUTE BROADCAST: [AUTO-SPAN]

FRAME TRANSLATION: [DISABLED]

SAVE [BRIDGE_PORT XX] RETURN

090835

Figure 8-1 The Bridge Setup Screen

8.1 BRIDGE SETUP SCREEN FIELDS

The following list describes each of the Bridge Setup screen fields:

Spanning Tree Protocol

Use this field to select a Spanning Tree protocol. Possible selections for this field are IEEE 802.1, DEC, or NONE.

Bridge Port Admin Status

Use this field to enable or disable individual MicroMMAC bridge ports. Possible selections for this field are ENABLED or DISABLED.

Bridge Port Pair Admin Status

Use this field to enable or disable bridging between bridge port pairs. For example, you can enable Port 1 to bridge traffic to all ports except Port 2.

Bridge_Port X

Use this command field to select the MicroMMAC bridge port you want to configure.

8.2 SELECTING A SPANNING TREE PROTOCOL

To select the Spanning Tree protocol to be used by the bridge, perform the following steps:

1. Use the arrow keys to highlight the **SPANNING TREE PROTOCOL** field.
2. Press SPACE or BACKSPACE to select **[IEEE 802.1]**, **[DEC]**, or **[NONE]**.
3. Use the arrow keys to highlight the **SAVE** command field.
4. Press ENTER. The Event Message field at the top of the screen displays "SAVED OK."

8.3 SELECTING THE PORT ADMINISTRATIVE STATUS

To select the bridge port administrative status, perform the following steps:

1. Use the arrow keys to highlight the **[BRIDGE_PORT XX]** field at the bottom of the Bridge Setup screen.
2. Press SPACE or BACKSPACE to select the bridge port you want to configure. The selected bridge port appears in the Bridge Port Admin Status field.
3. Use the arrow keys to highlight the **BRIDGE PORT ADMIN STATUS: PORT X - - > ALL PORTS [ENABLED]** field.
4. Press SPACE or BACKSPACE to select **ENABLE** or **DISABLE**.

For example, the following bridge setup indicates that bridge port 01 is configured to bridge traffic to all ports:

BRIDGE PORT ADMIN STATUS: PORT 01 - - > ALL PORTS [ENABLED]

5. Use the arrow keys to highlight the **SAVE** command field.
6. Press ENTER. The Event Message field at the top of the screen displays “SAVED OK.”

8.4 SELECTING THE BRIDGE PORT PAIR ADMINISTRATIVE STATUS

To select the bridge port pair administrative status, perform the following steps:

1. Use the arrow keys to highlight the **[BRIDGE_PORT XX]** field at the bottom of the Bridge Setup screen.
2. Press SPACE or BACKSPACE to select the bridge port you want to configure. The selected bridge port appears in the Bridge Port Pair Admin Status field.
3. Use the arrow keys to highlight the **BRIDGE PORT PAIR ADMIN STATUS: PORT X - -> PORT [Y]** field.
4. Press SPACE or BACKSPACE to select the port you want to enable or disable bridge traffic.
5. Use the arrow keys to highlight the **BRIDGE PORT PAIR ADMIN STATUS: PORT X - -> PORT [Y] [ENABLED]** field.
6. Press SPACE or BACKSPACE to select **ENABLE** or **DISABLE**.

For example, the following bridge setup indicates that bridge port 01 is configured NOT to bridge traffic to bridge port 02:


**BRIDGE PORT PAIR ADMIN STATUS: PORT 01 - - > PORT [02]
[DISABLED]**

7. Use the arrow keys to highlight the **SAVE** command field.
8. Press ENTER. The Event Message field at the top of the screen displays “SAVED OK.”

CHAPTER 9

COMPONENT STATUS SCREEN

Figure 9-1 shows the Component Status screen. The Component Status screen monitors the status of the MIB Components of the MicroMMAC.



090831

Figure 9-1 The Component Status Screen

The Component Status table lists the administrative status (Admin. Status) of the MicroMMAC MIB Components. The Admin. Status field displays two states: Enabled and Disabled. Refer to Figure 9-1 for a list of the MicroMMAC MIB Component Names.

CHAPTER 10

BRIDGE STATISTICS SCREEN

Figure 10-1 shows the Bridge (Device) Statistics screen. The Bridge Statistics screen displays error, collision, and traffic statistics for the entire network, a selected module, or a selected port. This screen also provides the option of enabling and disabling ports.

MicroMMAC Local Management Cabletron MicroMMAC Revision xx.xx.xx DEVICE STATISTICS			
	INTERFACE: 1	MODULE: 1	PORT: 1
BYTES RECEIVED:	0	0	0
FRAMES RECEIVED:	0	0	0
FRAMES FILTERED:			
FRAMES TRANSMITTED:			
ERRORS RECEIVED:	0	0	0
COLLISIONS:	0	0	0
OOW COLLISIONS:	0	0	0
CRC ERRORS:	0	0	0
ALIGNMENT ERRORS:	0	0	0
RUNT PACKETS:	0	0	0
GIANT PACKETS:	0	0	0
PORT ADMIN. STATUS:	0	0	ENABLED
PORT SEG. STATUS:	0	0	UNSEGMENTED
UPDATE -FREQ	3 Sec	ENABLE PORT INTERFACE 1	DISABLE PORT MODULE 1 PORT 1
			RETURN

090832

Figure 10-1 The Bridge Statistics Screen

10.1 BRIDGE STATISTICS SCREEN FIELDS

The following list describes Bridge Statistics screen fields:

Bytes Received

This field displays the number of bytes received.

Frames Received

This field displays the number of frames received.

Frames Filtered

This field displays the number of frames filtered by the MicroMMAC.

Frames Transmitted

This field displays the number of frames transmitted by the MicroMMAC.

Errors Received

This field displays the number of errors received.

Collisions

This field displays the number of collisions received.

OOW Collisions

This field displays the number of Out Of Window (OOW) collisions received.

CRC Errors

This field displays the number of packets with bad Cyclic Redundancy Checks (CRC) that have been received from the network.

Alignment Errors

This field displays the number of errors due to misaligned packets.

Runt Packets

This field displays the number of runt packets received from the network.

Giant Packets

This field displays the number of packets received whose size exceeded 1518 data bytes, not including preamble.

Port Admin. Status

This field displays the administrative status of the port selected. The two possible status messages are ENABLE or DISABLE.

Port Seg. Status

This field displays the segmentation status of the port selected. The two possible status messages are SEGMENTED or UNSEGMENTED. The MicroMMAC automatically partitions problem segments, and reconnects non-problem segments to the network.

Enable Port

Use this command field to enable a selected port.

Disable Port

Use this command to disable a selected port.

Update-Freq

Use this field to select the time interval between Interface/Module/Port counter updates. You can select update intervals in increments of 3 seconds, with the maximum interval being 99 seconds.

Interface

Use this command to select the interface you want to monitor.

Module

Use this command to view the statistics for a selected module in the stack. The MicroMMAC is module 1. Each SEH in the stack follows in sequential order. Figure 10-2 shows each module number in the stack.




Figure 10-2 Module Number Sequence

Port

Use this command to select and view port statistics for each MicroMMAC port.

10.2 SELECTING AN UPDATE-FREQ

The MicroMMAC updates the Bridge Statistics screen every three seconds by default. The UPDATE-FREQ command allows you to adjust the frequency in intervals of 3 seconds. The maximum update frequency is 99 seconds.

To adjust the UPDATE-FREQ, perform the following steps:

1. Use the arrow keys to highlight the **UPDATE-FREQ** command field.
2. Press **SHIFT-[+/=]** or **[-]** until the desired time/frequency appears (this number increments/decrements in 3 second intervals with a minimum of 3 seconds and a maximum of 99 seconds).
3. Press **ENTER**.

10.3 SELECTING AN INTERFACE/MODULE/PORT

When the Bridge Statistics screen first appears, statistics are displayed for Interface 1, Module 1 and Port 1. To view statistics for another interface, module, and port, use the **INTERFACE X**, **MODULE X**, or **PORT X** commands at the bottom of the screen.

To select an interface, module, or port, perform the following steps:

1. Use the arrow keys to highlight the **INTERFACE X**, **MODULE X**, or **PORT X** command field.
2. Press **SHIFT-[+/=]** or **[-]** until the desired interface, module, or port appears.
3. Press **ENTER**. Statistics associated with the selected interface, module, or port appear.

10.4 ENABLING PORTS

The **ENABLE PORT** command lets you enable the port selected in the **PORT** command field. You must first use the **PORT** command to select the desired port.

To set the **ENABLE PORT** command, perform the following steps:

1. Use the arrow keys to highlight the **ENABLE PORT** command field at the bottom of the screen.
2. Press ENTER.

10.5 DISABLING PORTS

The **DISABLE PORT** command lets you disable the port selected in the **PORT** command field. You must first use the **PORT** command to select the desired port.

To set the **DISABLE PORT** command, perform the following steps:

1. Use the arrow keys to highlight the **DISABLE PORT** command field at the bottom of the screen.
2. Press ENTER.

CHAPTER 11

MIB NAVIGATOR SCREEN

This chapter explains how to use the MIB Navigator utility. The MIB Navigator allows access to a command set from which you can configure and manage the MicroMMAC. Figure 11-1 shows the MIB Navigator screen.

```
Event Message Line
Welcome to MIB Navigator
MIBNav-> help
Navigation Commands:
branch      cd          ctron
dir          get          ls
mib2        next        pwd
set          su          tree
whoami

Other Commands:
arp          bridge      circuitmap
defroute     netstat     ping
reset        show        snmpbranch
snmpget      snmpset     snmpmtree
traceroute

SPECIAL:
done, quit, or exit - Exit from the MIB Navigator.
mib2 - Change directory to MIB II (/1/3/6/1/2/1).
ctron - Change directory to Cabletron MIB (/1/3/6/1/4/1/52).

For help with a specific command, type 'help <command>'.
MIBNav->
```

090829

Figure 11-1 The MIB Navigator Screen

11.1 MANAGING DEVICE MIBS

The MIB Navigator lets you manage objects in the MicroMMAC Management Information Bases (MIBs). MIBs are databases of objects used for managing the device and determining the MicroMMAC configuration. The commands within the MIB Navigator allow you to view and modify a device’s objects.

The MIB Navigator views the MIB tree hierarchy as a directory. Figure 11-2 shows the MIB tree hierarchy. Each layer is numerically encoded, so that every branch group and leaf object in the MIB is identified by a corresponding number, known as an Object Identifier (OID). This allows the MIB Navigator to navigate through the MIB and access the manageable leaf objects.




Figure 11-2 Hierarchical MIB Tree Structure

Often an ASCII name is assigned to the OID of a leaf object, making it more readable. To identify the value for the object “ip Forwarding” you would use the OID (/1/3/6/1/2/1/4/1), or its ASCII name (/iso/org/dod/internet/mgmt/mib-2/ip/ipForwarding).

11.2 MIB NAVIGATOR COMMAND SET OVERVIEW



Use the help command for an on-line description of each MIB navigator command. For example **MIB Nav-> help branch** provides help information for the branch command.

The MIB Navigator command set provides the following commands:

Navigation Commands

Navigation commands allow you to access and manage the MIB for the device running the MIB Navigator. Some of these commands also provide user community-string information. The commands are as follows:

– branch	– cd	–mib2	– dir
– get	– ls	–ctron	– next
– pwd	– set		– su
– tree	– whoami		

Other Commands

Other commands allow you to access and manage network devices connected to the device running the MIB Navigator. The commands are as follows:

– arp	– defroute	– netstat	– ping
– snmpbranch	– snmpget	– snmpset	– snmptree
– traceroute	– show	–reset	–bridge

Special Commands

Special Commands allow you to exit from the MIB Navigator. The commands are as follows:

– done	– quit	– exit
--------	--------	--------

11.2.1 Conventions for MIB Navigator Commands

This manual uses the following conventions for denoting commands:

- Information keyed by the user is shown in this helvetica font.
- Command arguments are indicated by two types of brackets:
 - required arguments are enclosed by [].
 - optional arguments are enclosed by < >.

MIB Navigator command conventions are as follows:

- To abort the output or interrupt a process the escape character is ^C (where ^ equals the Control key).
- A slash (/) preceeding an OID issues that command from the root directory regardless of where you are in the MIB. If no slash precedes the OID the command issues from your current MIB location.
- Dot notation (1.1.1.1) is equivalent to slash notation (1/1/1/1). Use slash notation with the navigational commands, and the dot notation with the built-in commands that are using SNMP to access and manage network devices.

MIB Navigation Commands are listed in the format shown below:

command:	
Syntax:	This entry provides the format that the MIB Navigator command requires. It indicates where arguments, if any, must be specified.
Description:	This entry briefly describes the command and its uses.
Options:	This entry lists any additional fields which may be added to the command and their format.
Example:	This entry shows an example of the command.

11.2.2 Navigation Commands

The following MIB Navigation commands allow you to move from MIB object to MIB object within the MIB tree.

branch:

Syntax: branch [path]

Description: The branch command displays all of the leaves in the MIB tree below a specified path. The information displayed includes the pathname, the object ASCII name, the type of object (i.e., integer, counter, time tick, etc.), and the current value of each leaf object.

Options: Not Applicable

Example:

```
MIBNav-> branch
```

```
# /1/3/6/1/2/1/7/1  udplnDatagrams  COUNTER  38216
# /1/3/6/1/2/1/7/2  udpNoPorts      COUNTER   0
# /1/3/6/1/2/1/7/3  udplnErrors     COUNTER   0
```

051456

cd:

Syntax: cd [path] or cd [option]

Description: The cd command allows you to change directories within a MIB subtree (branch). The path specified must be valid, or the MIB Navigator will not perform the cd operation.

Options: .. Moves you one subtree above the current one.
/ Moves you to the root.

Example:

```
MIBNav-> cd iso/org/dod/internet/mgmt
```

051457

ctron:

- Syntax:** ctron
- Description:** The ctron command allows you to change directories to the Cabletron MIB (1.3.6.1.4.1.52) without keying in the entire path.
- Options:** Not Applicable
- Example:**

MIBNav-> ctron

051458

help:

- Syntax:** help <COMMAND>
- Description:** The help command provides general help on how to use the MIB Navigator or how to use a particular MIB Navigator command.
- Options:** Not Applicable
- Example:**

MIBNav-> help su

Command: su
Format: su <Community Name>
Allows user to change his/her community name, in order to allow different access to the MIB.

051459

mib2:

Syntax: mib2

Description: The mib2 command allows you to move directly to the MIB II subtree (1.3.6.1.2.1) without entering the entire path.

Options: Not Applicable

Example:

```
MIBNav-> mib2
```

051460

next:

Syntax: next [path]

Description: The next command enables you to determine the next leaf in the specified path within the managed device's MIB.

Options: Not Applicable

Example:

```
MIBNav-> next /1/3/6/1/2/1
```

```
#/1/3/6/1/2/1/1/1 sysDescr String CtronRev.X.XX.XX
```

051461

pwd:

Syntax:	pwd
Description:	The pwd command displays the full pathname for the directory in which you are currently working. The directory is displayed in ASCII format.
Options:	Not Applicable
Example:	

MIBNav-> pwd

/iso/org/dod/internet/mgmt/mib-2

051462

set:

Syntax:	set <OID> <value>
Description:	<p>The set command enables you to set the value of a managed object. This command is valid only for leaf entries in the current MIB tree, or for managed objects in the MIB.</p> <p>If the leaf specified does not exist for the given path, MIB Navigator asks for a value. The following lists possible value types:</p> <ul style="list-style-type: none">(i)nteger - number(c)ounter - number(g)auge - number(t)ime ticks - numbero(p)aque - “value” (with quotation marks)(s)tring - “value” (with quotation marks)(o)id - OID number with dotted punctuation(a)ddress - IP address in DDN format(m)ac - MAC address in hexadecimal format(n)ull - no type
Options:	Not Applicable

Example:

```
MIBNav-> set /1/3/6/1/4/1/52/1/6/4/7 122.1.1.1
```

Type: (i)nteger (a)ddress (c)ounter (g)auge (o)id:

051463

su:

Syntax: su [community name]

Description: The su command enables you to change your community name to allow for different access to the MIB. The community name that you enter allows you either read only, read-write, or super-user access to that device's MIBs, depending on the level of security access assigned the password through the SNMP Community Names screen. Refer to Chapter 5 for more information about community names.

Options: Not Applicable

Example:

```
MIBNav-> su public
```

051464

tree:

- Syntax:** tree
- Description:** The tree command provides a display of the entire MIB for the device. Leaves and associated values are displayed in columns.
- Options:** Not Applicable
- Example:**

MIBNav-> tree

# /1/3/6/1/2/1/1/1	sysDescr	STRING	EMRev X.X.X.X
# /1/3/6/1/2/1/1/2	sysObjectId	OBJECT ID	1.3.6.1.4.1.52
# /1/3/6/1/2/1/1/3	sysUpTime	TIME TICKS	8098654
# /1/3/6/1/2/1/1/4	sysContact	STRING	AlZwie/MIS

051465

whoami:

- Syntax:** whoami
- Description:** The whoami command displays your community string and access privileges to the MIB. When using the whoami command one of these three access levels appears: read-only, read-write, and super-user.
- Options:** Not Applicable
- Example:**

MIBNav-> whoami

# Community Name	: super
# Access Level	: SuperUser

051466

11.2.3 Other Commands

The Other commands listed in this section activate functions on the LM managed device or devices being accessed through MIB Navigation.

arp:

Syntax: arp <options>

Description: The arp command provides access to the ARP (Address Resolution Protocol) cache, enabling you to view cache data, delete entries, or add a static route. Super-user access is required to delete an entry or add a static route.

Each ARP cache entry lists: the network *interface* that the device is connected to, the device's *network address* or IP address, the device's *physical address* or MAC address, and the *media type* of connection to the device. Media types are displayed as numbers, which stand for the following states:

- 1 - Other
- 2 - Invalid entry (cannot ping device, timed out, etc.)
- 3 - Dynamic route entry
- 4 - Static route entry (not subject to change)

Options:

- a View cache data
- d Delete an IP address entry. Requires additional arguments: <Interface Number> <IP address>
- s Add a static entry. Requires additional arguments: <Interface Number> <IP address> <MAC address>

Example:

```
MIBNav-> arp -a
# Interface      Network Address  Physical Address  Media Type
# (SonicInt)     122.144.40.111  00.00.0e.12.3c.04 3(dynamic)
# (SonicInt)     122.144.48.109  00.00.0e.f3.3d.14 3(dynamic)
# (SonicInt)     122.144.52.68   00.00.0e.12.3c.04 3(dynamic)
# (SonicInt)     122.144.21.43   00.00.0e.03.1d.3c 3(dynamic)

MIBNav-> arp -d 1 122.144.52.68

MIBNav-> arp -s 1 22.44.2.3 00:00:0e:03:1d:3c
```

051467

defroute:

- Syntax:** defroute [interface number] [IP address]
- Description:** The defroute command allows you to set the default IP route to a managed device through the specified interface.
- Options:** Not Applicable
- Example:**

```
MIBNav-> defroute 2 147.152.42.32
```

051469

netstat:

- Syntax:** netstat [option]
- Description:** The netstat command provides a display of general network statistics for the managed device. The netstat command must be used with one of the two display options.
- Options:**
- i Display status and capability information for each interface
 - r Display routing information for each interface

Example:

MIBNav-> netstat -i					
Interface + Description	MTU	Speed	Admin	Oper	MAC Addr
# 1 (ethernet - csmacd)	1514	10000000	up	up	0x00 0x00 0x1d 0x07 0x50 0x0e
# 2 (ethernet - csmacd)	1514	10000000	up	up	0x00 0x00 0x1d 0x07 0x50 0x0f
# 3 (ethernet - csmacd)	1514	10000000	up	up	0x00 0x00 0x1d 0x07 0x50 0x10
# 4 (ethernet - csmacd)	1514	10000000	up	up	0x00 0x00 0x1d 0x07 0x50 0x11
MIBNav-> netstat -r					
Destination	Next-hop	Interface			
# Default Route	DirectConnection	1			
# 134.141.0.0	DirectConnection	2			
# 134.141.0.0	DirectConnection	3			

051470

ping:

Syntax: ping [IP address]

Description: The ping command generates an outbound ping request to check the status (alive/not alive) of a device at a specified IP address.

Options: Not Applicable

Example:

MIBNav-> ping 122.144.40.10
122.144.40.10 is alive

051471

snmpbranch:

- Syntax:** snmpbranch [IP address] [community name] [OID]
- Description:** The snmpbranch command enables you to query another SNMP device. The command provides a display of objects that match the specified OID. If no match is made, no object is displayed.
- Options:** Not Applicable
- Example:**

MIBNav-> snmpbranch 2.4.8.1 public 1.3.6.2.1.1

# /1/3/6/1/2/1/1/1	sysDescr	STRING	EMRev X.X.X.X
# /1/3/6/1/2/1/1/2	sysObjectld	OBJECT ID	1.3.6.1.4.1.52
# /1/3/6/1/2/1/1/3	sysUpTime	TIME TICKS	8098654
# /1/3/6/1/2/1/1/4	sysContact	STRING	AlZwie/MIS

051473

snmpget:

- Syntax:** snmpget [IP address] [community name] [OID]
- Description:** The snmpget command enables you to query another SNMP device to obtain a value for a specified object. This command requires the appropriate community string and object id.
- Options:** Not Applicable
- Example:**

MIBNav-> snmpget 22.44.61.22 public 1.3.6.1.2.1.1.1.0

Cabletron EMME Revision X.XX.XX

051474

snmpset:

Syntax: snmpset [IP address] [community name]

Description: The snmpset command enables you to set the value of an object in other SNMP devices. This command requires the appropriate community string and OID.

When defining a new leaf set, MIB Navigator asks for a value. The following lists possible value types:

- (i)nteger - number
- (c)ounter - number
- (g)auge - number
- (t)ime ticks - number
- o(p)aque - “value” (with quotation marks)
- (s)tring - “value” (with quotation marks)
- (o)id - OID number with dotted punctuation
- (a)ddress - IP address in DDN format
- (m)ac - MAC address in hexadecimal format
- (n)ull - no type

Options: Not Applicable

Example:

```
MIBNav-> snmpset 122.44.1.2 public
1.3.6.1.2.1.1.4.0 "Cyrus/MIS"
```

051475

snmptree:

- Syntax:** snmptree [IP address] [community name]
- Description:** The snmptree command provides a display of all objects in the device and their corresponding values.
- Options:** Not Applicable
- Example:**

MIBNav-> **snmptree 122.144.89.10 public**

# /1/3/6/1/2/1/1/1	sysDescr	STRING	EMRev X.X.X.X
# /1/3/6/1/2/1/1/2	sysObjectld	OBJECT ID	1.3.6.1.4.1.52
# /1/3/6/1/2/1/1/3	sysUpTime	TIME TICKS	8098654
# /1/3/6/1/2/1/1/4	sysContact	STRING	AlZwie/MIS

051476

traceroute:

- Syntax:** traceroute [IP address]
- Description:** The traceroute command generates a TRACEROUTE request to a specified IP address and provides a display of all next-hop routers in the path to the device. If the device is not reached, the command displays all next-hop routers to the point of failure.
- Options:** Not Applicable
- Example:**

MIBNav-> **traceroute 122.144.11.52**

```
# next-hop[1] 122.144.61.45
# next-hop[2] 122.144.8.113
```

051477

11.2.4 Special Commands

done, quit, exit:

Syntax: done

Description: These commands enable you to exit from the MIB Navigator and return to the Main Menu screen.

Options: Not Applicable

Example:

```
MIBNav-> done
```

```
Connection closed
```

051472

INDEX

A

- Auto-Baud Detection
 - activating 3-1
 - definition 4-4

B

- Baud Rate 4-4, 4-9
- Bridge Setup
 - bridge port pair administrative status 8-4
 - port administrative status 8-3
 - spanning tree protocol 8-2
- Bridge Statistics
 - alignment errors 10-2
 - bytes received 10-1
 - collisions 10-2
 - CRC errors 10-2
 - disable port 10-5
 - disable port 10-3
 - enable port 10-3, 10-5
 - errors received 10-2
 - frames filtered 10-2
 - frames received 10-1
 - giant packets 10-2
 - interface 10-3, 10-4
 - module 10-3, 10-4
 - port 10-3, 10-4
 - port admin. status 10-2
 - port seg. status 10-2
 - runt packets 10-2
 - update-freq 10-4

C

- Caution 1-8
- COM 1 Application 4-3, 4-8
- COM 2 Application 4-8

D

- Default Gateway 4-3, 4-6
- Default Interface 4-3, 4-7

F

- Flash Download
 - bootprom 7-3
 - runtime 7-2

H

- Host IP Address 4-2, 4-5

K

- Keyboard Conventions 1-6

L

- Local Management
 - exiting screens 3-4
 - navigating menu screens 3-2
 - requirements 1-3
 - selecting menu screen items 3-3
- Local Management Screen Fields
 - command fields 1-5
 - display fields 1-5
 - event message field 1-5
 - input fields 1-5
 - selection fields 1-5

M

- Management Agent 1-2
- Management Terminal
 - cable configuration 2-3
 - setup requirements 2-2

MIB

- description 11-2
- tree hierarchy 11-2
- MIB Components 9-1
- MIB Navigator
 - exiting 11-3
 - navigation commands 11-3
 - other commands 11-3
 - special commands 11-3

N

Network Management

in-band 1-3

local 1-3

out-of-band 1-3

remote 1-3

Note 1-8

O

Out of Band IP Addr 4-2, 4-6

P

Phys Address 4-3

S

SNMP Community Names

read-only 5-2

read-write 5-2

super-user 5-2

SNMP Traps

enable traps 6-2

trap community name 6-2

trap destination 6-2

Subnet Mask 4-3, 4-7

System Date 4-2, 4-4

System Level Screen

fields 4-2

System Time 4-2, 4-5

T

Telnet 2-4

Tip 1-8

U

update-freq 10-3

UPS

cable configuration 2-4